


Collered status button


Warning!


A warning message box with a red exclamation mark icon. The text inside reads: 'Water is pumped. Have a bucket/jerrycan ready (appr. 10 liter, on...'. Below the text is a faint, mirrored version of the box.





TAB number


next tab present

























Not preferable.  
The salt content will be increased  
above the preferred value by the  
water change.








 Water is pumped to drain!  
Have a bucket/jerrycan ready under the drain pipe.  
(appr. 10 liter, one full bucket)



















Valves are checked on close state. It is not possible to open valves by hand (result malfunction valve)



Valves are not checked on close state. It is possible to open valves by hand before going to state ROUTE.



Arduino Finite State Machine  
Copyright(C) 2021 Jelle Siemonsma

This program is free software : you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

< <https://www.gnu.org/licenses/>>.